



Formulation

RINSE AID, HIGH GLOSS

102550-27

INGREDIENTS:

	INGREDIENTS	% W/W
A	Butyl diglycol (BDG) (2-(2-Butoxyethoxy) ethanol)	12.0
	DOWANOL DPnB (Dipropylene Glycol n-Butyl Ether)	8.0
	TEGOSOFT® DEC (Diethylhexyl Carbonate)	10.0
	REWOPON® IM OA (1-Hydroxyethyl 2-Heptadecenyl Imidazoline)	1.0
B	Acetic acid (Acidum Aceticum)	0.5
C	REWOQUAT® CR 3099 (Di Oleic Acid Isopropylester Dimethylammonium Methosulfate)	2.0
	REWOQUAT® W 3690-90 (1-Methyl-2-Noroleyl-3-Oleic Acid-Aminoethyl-Imidazolinium-Methosulfate)	10.0
D	Water	54.0
E	TEGOPREN® 6922 (Quaternium-80)	0.5
	Silicone oil AK 1 (Polydimethylsiloxan, 1mm ² /s)	2.0

PROCESSING

Blend 1-4 while stirring. Stir until clear. Add acetic (5) acid while stirring. Add 6 and 7 and stir until the mixture is clear. Add the water and stir until clear. Finally add 9 and 10 while stirring. Adjust the pH to pH 4-5 with acetic acid.

Disclaimer:

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third-party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

Evonik Nutrition & Care GmbH

Rodenbacher Chaussee 4
63457 Hanau, Germany
Phone +49 6181 59-6338
Fax +49 6181 59-6338

**info-household-
care@evonik.com**

**[www.evonik.com/household-
care](http://www.evonik.com/household-care)**