



Formulation

## LEATHER CARE, GEL

102360-1

### INGREDIENTS:

	INGREDIENTS	% W/W
A	TEGOPREN® 6800 (Stearyl Dimethicone )	1.8
	TEGOPREN® 7008 (Cetyl Dimethicone Copolyol)	1.6
	TEGO® Polish Additiv 5 (Cyclomethicone)	7.2
	TEGOSOFT® M (Isopropyl Myristate )	3.6
	Silicone oil, medium viscous (Silicone oil (300 - 1000 mPas))	1.8
B	Glycerin (1,2,3-Propanetriol)	48.4
	Sodium chloride	2.5
	Water	33.1
	Preservative	t. q.

### PROCESSING

Mix separately Phase A and Phase B until homogenous. Add Phase B into Phase A while intensive stirring and continue stirring at same speed for approx. 5 min.

### REMARKS

To achieve a clear gel both phases should have the same refraction index.

**Disclaimer:**

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third-party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

**Evonik Nutrition & Care GmbH**

Rodenbacher Chaussee 4

63457 Hanau, Germany

Phone +49 6181 59-6338

Fax +49 6181 59-6338

**info-household-care@evonik.com****[www.evonik.com/household-care](http://www.evonik.com/household-care)**